



- NOTE: 1. FOR DEVICE FUNCTIONS SEE APPROPRIATE DEVICE TEMPLATES.
2. A COORDINATOR MUST BE USED ON INACTIVE DOOR.

1609 J Strike for 3327/3527 Vertical Rod & 33/35 Rim Series Devices

VON DUPRIN®

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE NUMBER:

30037_a

DATE: 05-23-13