






## **IMPORTANT-**

Please check door width before fitting and ensure correct template size is used.




- 242
- The door closer is pre-set at #3 power.
- Maximum opening angle at 180°.
- Maintenance: Check quarterly to ensure correct setting of door closing and latching speeds and that fixing screws are tight. A small amount of oil applied to door hinges and the arm joints and rollers will assist performance.






- Determine the installation position of the door closer place the template on the closed door and the top jamb, and make holes in them with a punch or other proper tools
- ① Template




- Fit the lever to the pinion shaft and fix it firmly with the screw.
- Mount the closer on the door
- ① Link shoe
- ② Door closer ③ Lever
- Mounting screw



- and fix with the lock nut.
- FIX PINION CAP TO CLOSER BODY

OVER ADJUSTMENT WILL LEAD TO OIL LEAKAGE WHICH WILL AFFECT THE PERFORMANCE OF THE CLOSER. IN SUCH INSTANCES OUR GUARANTEE BECOMES VOID



Adjust the closing speed.

The door closer closes the door at two different speeds. The first speed can be controlled by the No.1 speed adjusting valve, and the second speed, by the No.2 speed adjusting valve.

① CLOSING

@LATCHING

Size Force



- +	Size Force	Max. door width
About -5 turns About 0 turn About +5 turns About +9 turns	2345	850mm 950mm 1100mm 1250mm


**Delayed Action** 

**Back Check** 









850mm 950mm 1100mm

About About -5 turns 0 turn

About +5 turns About +9 turns