

L Service Manual

Trim Assemblies Chart

P/N	Description	L0170	L0172	L460	L462	L463	L464	L480	L496	L9010	L9040	L9040	L9040/XL11-446**	L9040/XL11-446**	L9044*	L9044	L9050	L9050	L9050	L9056	L9056	L9060	L9060	L9070	L9070	L9071	L9071	L9076	L9076	L9077	L9077	L9080	L9080	L9080	L9080EL	L9080EL	L9080EU	L9080EU	L9080EU-L-RX	L9080EU-L-RX	L9082	L9082	L9082EL	L9082EL								
		A	09-401	O/S Knob & Lever	•						•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			
B	09-402	I/S Knob & Lever	•	•					•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
C	09-403	I/S Rose	•	•					•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			
D	09-404	O/S Rose & Bushing	•						•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			
E		Outside Rose & Knob/Lever:																																																		
	09-506	All design except AST, AVA, MER and 93	•						•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			
	09-655	AST, AVA, MER and 93	•						•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		
F	09-509	Thumbturn		•				•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		
	L283-124	Coin turn outside													•	•																																				
G		Outside Escutcheon x Knob/Lever except 93 lever:																																																		
	09-550	L & N x blank	•						•																																											
	09-550/ XL11-446	L x thumbturn †											•	•																																						
	09-551	L & N emergency button							•	•																																										
	09-553	L & N x full face cylinder															•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	09-554	L x concealed cylinder/indicator																																																		
	09-555	L x full face cylinder/indicator																																																		
H	09-611	Occupancy Indicator							•																																											
I		Inside Escutcheon for Knob/Lever:																																																		
	09-632	L & N x blank	•	•					•																																											
	09-633	L & N x thumbturn							•	•	•	•					•	•	•	•																																
	09-635	L & N x full face cylinder																				•	•				•	•																								

† Not sold separately as a part.
 * Available with rose trim only.
 ** Not available with N escutcheon.

NOTE: Standard cylinder part numbers are shown for cylinder function locks. See pages 103–113 for other cylinder options.



Trim Assemblies Chart

	P/N	Description	L9110/XL11-741	L9175	L9176	L9177 (disc)	L9178 (disc)	L9440	LV9440	L9444*	LV9444*	L9453	LV9453	L9456	LV9456	L9457	LV9457	L9460	L9460/XL11-635	L9460/XL11-886	L9462	L9462/XL11-886	L9463	L9464	L9464/XL11-886	L9465	L9466	L9473	L9480	LV9480	L9482/XL11-543	LV9482/XL11-543	L9485	LV9485	L9485/XL11-557**	L9486***⌘	LV9486***⌘	L9496	LV9496													
			A	09-401	O/S Knob & Lever	•		•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
B	09-402	I/S Knob & Lever	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•					
C	09-403	I/S Rose	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•					
D	09-404	O/S Rose & Bushing	•		•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•					
E Outside Rose & Knob/Lever:																																																				
	09-506	All design except AST, AVA, MER and 93	•		•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
	09-655	AST, AVA, MER and 93	•					•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			•				•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
F	09-509	Thumbturn						•	•	•	•	•	•	•	•	•	•	•	•	•	•								•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
	L283-124	Coin turn outside								•	•																																									
G Outside Escutcheon x Knob/Lever except 93 lever:																																																				
	09-550	L & N x blank	•		•		•																																													
	09-550/ XL11-446	L x thumbturn †																																																		
	09-551	L & N emergency button						•	•																																											
	09-553	L & N x full face cylinder										•	•	•	•	•	•	•	•	•	•	•			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		
	09-554	L x concealed cylinder/indicator																																																		
	09-555	L x full face cylinder/indicator																																																		
H	09-611	Occupancy Indicator																																																		
I Inside Escutcheon for Knob/Lever:																																																				
	09-632	L & N x blank	•	•	•	•	•																			•	•																									
	09-633	L & N x thumbturn					•	•				•	•	•	•					•	•							•	•	•																						
	09-635	L & N x full face cylinder														•	•											•																								

† Not sold separately as a part.
 * Available with rose trim only.
 ** Available with knob x rose trim only.
 *** Not available with N escutcheon.
 ⌘ L9486 and LV9486 available with "Occupied" indicator option. Specify 09-611 x L583-375.

NOTE: Standard cylinder part numbers are shown for cylinder function locks. See pages 103–113 for other cylinder options.

Trim Assemblies Chart

P/N	Description	L9110/XL11-741	L9175	L9176	L9177 (disc)	L9178 (disc)	L9440	LV9440	L9444*	LV9444*	L9453	LV9453	L9456	LV9456	L9457	LV9457	L9460	L9460/XL11-635	L9460/XL11-886	L9462	L9462/XL11-886	L9463	L9464	L9464/XL11-886	L9465	L9466	L9473	L9480	LV9480	L9482/XL11-543	LV9482/XL11-543	L9485	LV9485	L9485/XL11-557**	L9486***⌘	LV9486***⌘	L9496	LV9496			
J Outside Escutcheon & Bushing x Knob/Lever Except 93 Lever:																																									
09-636	L & N x blank	•	•	•																																					
09-636/ XL-446	L x thumbturn†																																								
09-637	L & N x emergency button					•	•																																		
09-639	L & N x full face cylinder										•	•	•	•	•	•		•	•		•			•	•	•	•	•	•	•	•	•	•	•							
09-640	L x concealed cylinder/ind.																																								
09-641	L x full face cylinder/ind.																																			•	•	•	•		
Outside N Escutcheon & Bushing x 93 Lever:																																									
09-650	Blank			•	•																																				
09-651	Emergency Button					•	•																																		
09-652	Full face Cylinder										•	•	•	•	•	•								•	•	•	•	•					•	•							
K 1¼" Armor Front x Schlage Logo:																																									
09-661	Blank	•	•	•																																					
09-662	Latch																																								
09-663	Latch & aux. latch																																								
09-664	Latch & deadbolt					•	•	•	•			•	•	•	•								•	•	•														•	•	
09-665	Deadbolt																•	•	•	•	•	•	•	•	•																
09-666	Latch, aux. latch and deadbolt										•	•															•	•	•	•	•	•	•	•	•	•	•	•			
09-713	Latch, aux. latch less UL stamp																																								
09-717	L400-Series deadbolt																																								
L																																									
09-905	Classroom Turn & 1½" Blocking Ring																					•																			
M Full Face Cylinder with Compression Ring and Spring:																																									
20-001	Straight cam																																								
30-001	Clover leaf cam										•	•	•	•	2	2	•	•	•	2	2	•	•	•	•	2	•	•	•	2	2	•	•					•	•		
30-002	Hotel (handed)																																				•	•	•		

† Not sold separately as a part.
 * Available with rose trim only.
 ** Available with knob x rose trim only.
 *** Not available with N escutcheon.
 ⌘ L9486 and LV9486 available with "Occupied" indicator option. Specify 09-611 x L583-375.

NOTE: Standard cylinder part numbers are shown for cylinder function locks. See pages 103–113 for other cylinder options.

Trim Assemblies Chart

P/N	Description	L0170	L0172	L460	L462	L463	L464	L480	L496	L9010	L9040	LV9040	L9040/XL11-446**	LV9040/XL11-446**	L9044*	LV9044	L9050	LV9050	L9056	LV9056	L9060	LV9060	L9070	LV9070	L9071	LV9071	L9076	LV9076	L9077	LV9077	L9080	LV9080	L9080EL	LV9080EL	L9080EU	LV9080EU	L9080EL-RX***	LV9080EL-RX***	L9082	LV9082	L9082EL	LV9082EU		
		CC	Assembled Lock Case:																																									
F506-237	Wood doors x L escutcheon	2																																										
L583-066	Wood/metal doors x rose/esc x knob/lever except single dummy	2								2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	
L583-290	Wood/metal doors x rose/escutcheon x lever	2																																										
L583-291	Wood/metal doors x rose/escutcheon x knob	2																																										
DD	L583-195 Compression Spring			•	2	•	•		•							•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
EE	L583-212 Mounting Posts, L	2								2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	
	L583-497 Mounting Posts, LV											2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	
FF	L583-233 Emergency Turn											•	•																															
GG	L583-286 Dummy Mounting Bar	•	•																																									
HH	L583-321 I/S Knob Mounting Plate	•	•							•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
II	L583-322 Lever Spacer	•	2																																									
JJ	10-091 Armor Strike																																											

* Available with rose trim only.
 ** Available with knob x rose trim only.
 *** Not available with N escutcheon.

NOTE: Standard cylinder part numbers are shown for cylinder function locks. See pages 103–113 for other cylinder options.



Trim Assemblies Chart

P/N	Description	L9110/XL11-741	L9175	L9176	L9177 (disc)	L9178 (disc)	L9440	LV9440	L9444*	LV9444*	L9453	LV9453	L9456	LV9456	L9457	LV9457	L9460	L9460/XL11-635	L9460/XL11-886	L9462	L9462/XL11-886	L9463	L9464	L9464/XL11-886	L9465	L9466	L9473	L9480	LV9480	L9482/XL11-543	LV9482/XL11-543	L9485	LV9485	L9485/XL11-557**	L9486***⌘	LV9486***⌘	L9496	LV9496							
CC	Mounting Plate Screws:																																												
	F506-237	Wood doors x L escutcheon																																											
	L583-066	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2			
	L583-290	2		2																																									
	L583-291	2		2																																									
DD	L583-195										•	•	•	•	2	2	•	•	•	•	2	2	•	•	•	•	2	•	•	•	•	2	2	•	•	•	•	•	•	•	•	•	•		
EE	L583-212	2		2		2	2		2		2		2		2		2	2		2		2		2	2	2	2	2		2		2		2		2		2		2		2			
	L583-497							2	2		2		2		2													2		2		2		2					2				2		
FF	L583-233						•	•																																					
GG	L583-286																																												
HH	L583-321	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
II	L583-322	•	2	•	2												2	•	•					•			•		2		•		2	•				•			•				
JJ	10-091			•	•																																								

* Available with rose trim only.
 ** Available with knob x rose trim only.
 *** Not available with N escutcheon.
 ⌘ L9486 and LV9486 available with "Occupied" indicator option. Specify 09-611 x L583-375.

NOTE: Standard cylinder part numbers are shown for cylinder function locks. See pages 103–113 for other cylinder options.