



Hambleton Avenue, Devizes, Wiltshire, SN10 2RT Tel: 01380 729600 Fax: 01380729888

WATERLESS URINAL MAINTENANCE & CLEANING INSTRUCTIONS

General Maintenance

Maintaining a satisfactory level of Blue Seal liquid is vital to the correct operation of our Waterless Urinals. Always ensure you keep enough stock to service your urinals.

The urinals are equipped (upon despatch) with a Portion-Aid to assist in the accurate dispensing of the correct amount of fluid. Each 85ml refill will last for approximately 1500 uses per urinal. The following table will give you a guide to the 'top-up' regularity.

<u>Approximate uses per day</u>	<u>Refill intervals</u>
<50	Monthly
51<100	2 x per month
101<150	3 x per month
150 plus	Weekly

Task time per urinal – less than a minute

Procedure –

- Do not remove the trap from the urinal
- Screw the portion aid to the Blue Seal bottle
- Carefully squeeze the bottle to fill the receptacle to the desired level
- Pour the Blue Seal liquid directly into the Eco-Trap towards the back of the urinal

Exchanging the Trap

The Eco-Trap plastic insert needs occasional replacement to deal with any build-up of sediment. Do not attempt to clean the used trap. The 'Extractor Tool' is provided for safe trap removal.

Always dispose of the used trap carefully.

Cleaning Instructions

Normally, all urinals should be cleaned at least daily. Very busy environments may dictate that cleaning routines are carried out on a more regular basis. Cleaning routines should follow these guidelines:

- Remove any foreign objects and other debris from the base of the urinal
- Use only proven non-abrasive cleaning fluids
- Apply to **all surfaces** of the urinal paying particular attention to the lower front of the urinal
- Wipe down all surfaces with a soft sponge paying particular attention to the lower front of the urinal
- Spray all surfaces with water from water spray bottle to loosen cleaner suds. Alternatively use a soaked and rinsed sponge
- Dry all surfaces with a soft cloth or soft rag

**NEVER POUR WATER DIRECTLY INTO THE URINAL –
THIS WILL DISPERSE THE BLUE SEAL LIQUID**