



ESCUTCHEONS




THIS VERSION OF THE KEYLEX 700 (K700AR TO SUIT ADAMS RITE LOCK CASES) IS PROVIDED WITH TWO BLANK ESCUTCHEONS SINCE THE KEY OVERRIDE OPTION IS NOT AVAILABLE.




HANDING THE LEVER

ROTATE THE QUADRANT SPINDLE CLOCKWISE OR ANTI-CLOCKWISE TO SET THE REQUIRED HAND



1. TO RELEASE THE LEVER FROM THE UPRIGHT POSITION, GRIP THE LOCK BODY FIRMLY IN ONE HAND AND THE LEVER FIRMLY IN THE OTHER. MOVE THE LEVER THROUGH 90 DEGREES TO EITHER THREE O'CLOCK OR NINE O'CLOCK (AS REQUIRED). YOU WILL FEEL A 'CLICK'.
2. LIFT THE LEVER THROUGH 45 DEGREES UNTIL THE LEVER SHAFT HOLE LINES UP WITH THE HOLE IN THE LEVER.
3. SET THE LEVER BY TIGHTENING THE GRUB SCREW WITH THE ALLEN KEY (BOTH SUPPLIED IN THE HARDWARE PACK). ALLOW THE LEVER TO RETURN TO THE HORIZONTAL POSITION.




HOW TO OPERATE THE LOCK USING THE PRE-SELECTED CODE.

1. PRESS BUTTON "C" TO CLEAR ANY SPURIOUS CODE.
2. PUSH APPROPRIATE BUTTONS IN THE PRE-SELECTED CODE.
3. ROTATE THE LEVER DOWNWARD TO OPEN THE DOOR.

OUTSIDE

INSIDE



1. PREPARE THE DOOR IN ACCORDANCE WITH THE TEMPLATE. ENSURE THAT YOU MAKE THE CORRECT CHOICE OF BACKSET LENGTH. CHECK THIS CAREFULLY AGAINST THE CHOSEN LOCK CASE.
2. INSTALL THE LOCK CASE AND STRIKE PRIOR TO INSTALLING THE MAIN LOCK BODY.
3. MOUNT THE OUTSIDE LOCK BODY AS SHOWN AT EACH OF THE AVAILABLE POINTS.
4. REFER TO THE SECTION BELOW FOR CODE SETUP. ENSURE THAT THE CODE IS TESTED AND THAT THE LOCK WORKS SATISFACTORILY BEFORE ALLOWING THE DOOR TO CLOSE.
5. CAM DISC ASSEMBLIES* (BY OTHERS) ARE REQUIRED TO EACH SIDE OF THE DOOR TO ACCEPT EACH SPINDLE. PLEASE USE THE CAM DISC ASSEMBLY AS A TEMPLATE WHEN PREPARING FOR INSTALLATION.

PROTECTING THE DIGITAL LOCK MECHANISM


SLIPPING CLUTCH MECHANISM




NULLIFIES FORCED ATTACK OR VANDALISM FROM THE OUTSIDE
PROTECTS THE INTERNAL GEAR MECHANISM

RESETTING THE SLIPPED CLUTCH ON THE KEYLEX 700AR IS STRAIGHTFORWARD
FOLLOW THE PROCEDURE OUTLINED BELOW


STANDARD
LEVER POSITION



SLIPPED AND RESET POSITION



A SLIPPED CLUTCH LEVER
POINTS DIRECTLY DOWN
AT 90° FROM THE
STANDARD POSITION



LIFT THE LEVER THROUGH 90° TO
RESET THE HORIZONTAL POSITION
YOU WILL FEEL A 'CLICK' AS YOU LIFT.
ALLOW THE LEVER TO REST IN THE
HORIZONTAL POSITION

LOCK OPERATION & FUNCTION DESCRIPTION

Clearing Codes




It is essential that any 'spurious' code be cleared before operation of the lock from the outside. The 'C' clear button should be pressed as a precursor to the entry of your code.

Entering Codes

Codes should be ideally selected to contain between 3 and 6 digits and can include a mixture of letters and numerals. Buttons may be pressed in any order and must be pushed firmly to engage the code. Once the correct code is entered the lock may be used. If mistakes are made you may clear the code using the procedure described above.

Changing Codes

Code changing is fast and straightforward requiring only a slotted screwdriver once the lock body is removed from the door. Each button is marked with a single line at right angles to the screwdriver slot with corresponding marks adjacent on the back plate. Rotate the button to align the two marks thus setting that button as part of the code.



Door, Security and Washroom Hardware

Relcross Ltd.,
Hambleton Avenue,
Devizes, Wiltshire
SN10 2RT United Kingdom


Tel: 01380 729600
Fax: 01380 729888
Email: sales@relcross.co.uk
Internet: www.relcross.co.uk

IMPORTANT
INSTALLATION NOTE

THIS PRODUCT IS DESIGNED TO WORK
WITH THE ADAMS RITE CAM DISC
ASSEMBLY (x2) WHICH ULTIMATELY
DRIVES THE LOCK CASE.

THE DOOR PREPARATION SHOWN ON
THE TEMPLATE DOES NOT TAKE THIS
PART INTO ACCOUNT.

WHERE NECESSARY, THE CAM DISC
SHOULD BE USED AS A TEMPLATE.



Relcross Ltd.,
Hambleton Avenue,
Devizes, Wiltshire
SN10 2RT United Kingdom

Tel: 01380 729600
Fax: 01380 729888
Email: sales@relcross.co.uk
Internet: www.relcross.co.uk